SST LIST

2

	Page	
090 ## — #####	2	090
091 ## — #####	2	091
092 ## — #####	2	092
093 ## — #####	22	093
094 ## — #####	34	094
095 ## — #####	34	095
096 ## — #####	42	096
097 ## — #####	58	097
098 ## — #####	66	098
099 ## — #####	70	099

Section				ENGINE																					AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																						
Part No.																																						
Illustration																																						
	09023-00100	Union Nut Wrench 10 mm	B																																			
	09032-00100	Oil Pan Seal Cutter	A	*	*	*		*	*	*	*		*	S	*	*	*	*	*	*	*	*	*	*					*	*									
	**09043-38100**	Hexagon 10 mm Wrench	A																	S							*		S1 S2		*	*				*			
	**09043-88010**	Hexagon 8 mm Wrench	A																	S					S1														
	★ **09081-00011**	Alternator Checker	C				*					*																											
	09082-00700	SRS Air Bag Deployment Tool	C																																			
	09082-00720	SRS Air Bag Deployment Wire	C																																			
	**09082-00730 NEW**	Airbag Deployment Wire Sub-harness No. 1	C																																			
	★ **09201-10000**	Valve Guide Bushing Remover & Replacer Set	B	*	*	*		*	*	*	*	*	*	*		*	*	*	*	*	*	*	S	*	*	TR	*	*	S1 TR	* TR	*	*	*		*		*		* TR
	09201-01055	Valve Guide Bushing Remover & Replacer 5.5	B												*																							
	**09201-31010**	Valve Stem Oil Seal Replacer	B																				*															
	**09201-41020**	Valve Stem Oil Seal Replacer	B	S		S1			S1				*	*	*	*	*	*	*	*	*	*	*		*													

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification / Part Name / Part No. / Illustration				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	**09201-76020**	Valve Stem Guide Remover & Replacer	B				*																														
	09201-77010	Valve Stem Oil Seal Replacer	B				*																														
	★ **09202-70020**	Valve Spring Compressor	A	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*													
	09205-16010	Cylinder Head Bolt Wrench	A	*																																	
	**09205-76030**	Cylinder Head Setting Bolt Tightening Adaptor	A				*				*									S			S_1														
	09207-76010	Rocker Arm Bushing	B				*												*		*																
	09208-48010	Combustion Chamber Remover	B		*		*						*	S			S_1																				

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	F Z series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	★ **09213-14010**	Crankshaft Pulley Holding Tool	A	S		*		*				*								S_1																	
	★ **09213-54015**	Crankshaft Pulley Holding Tool	A	S_1						*			*	*				*	*			S	*															
	★ **09213-58013**	Crankshaft Pulley Holding Tool	A		*				*				*				*				*		S															
	★ **09213-70010**	Crankshaft Pulley Holding Tool	A	*							*					*		*	*			S	G	*														
	09214-41010	Crankshaft Damper & Gear Replacer	B				*																															
	09214-60010	Crankshaft Pulley & Gear Replacer	B			*		*		*		*		*			*						S															
	09214-76011	Crankshaft Pulley Replacer	B				*						*				*																					
	★ **09215-00013**	Camshaft Bearing Remover & Replacer Set "B"	C		*		*																*															
	★ **(09215-00100) 09215-00101**	Camshaft Bearing Remover & Replacer Set "A"	C		*		*					*											*	*														

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09218-46010	Cylinder Liner Remover & Replacer	B																																		
	09218-54011	Cylinder Liner Remover & Replacer	B																																	RA	
	09218-56010	Cylinder Liner Remover & Replacer	B																																	RA	
	**09218-56030**	Cylinder Liner Remover & Replacer	B																																	FA	
	★ **09218-76013**	Cylinder Liner Remover & Replacer	C				*																														
	★ **09219-56010**	Piston Cooler Remover	B		*																																
	★ **(09221-25025) 09221-25026**	Piston Pin Remover & Replacer	B	*				*		*		*								S			*		*													
	**09221-76011**	Piston Pin Remover & Replacer	B				*																														
	★ **09222-17011**	Connecting Rod Bushing Remover & Replacer	B														S																				
	09222-30010	Connecting Rod Bushing Remover & Replacer	B								*	*			*			*		*		*	*														
	09222-40011	Connecting Rod Bushing Remover & Replacer	B											S							*																

| Section | MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																					AT					MT						
Classification			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	★ 09222-54011	Connecting Rod Bushing Remover & Replacer	B										S																								
	★ 09222-58012 NEW	Connecting Rod Bushing Remover & Replacer	B		S																																
	★ 09222-58021	Connecting Rod Bushing Remover & Replacer	B		S																																
	★ 09222-64012	Connecting Rod Bushing Remover & Replacer	B			*							S																								
	09222-66010	Connecting Rod Bushing Remover & Replacer	B		S										*	S_1																					
	★ 09222-67011	Connecting Rod Bushing Remover & Replacer	B									*																									
	09222-76012	Connecting Rod Bushing Remover & Replacer	B				*																														
	★ 09222-78012	Connecting Rod Bushing Remover & Replacer	B																			*															
	09223-00010	Cover & Seal Replacer	B						*			*		*		*											TR	TR									
	09223-15020	Oil Seal and Bearing Replacer	B	*				S		*		*					*								TR		S_2	S_3	S_1	*			*	*	*	* S_3	S_3
	09223-15030	Oil Seal and Bearing Replacer	B	S				S_1	*	*	*		*	*	*	*		*	*	*			*		*					S_2								
	09223-22010	Crankshaft Front Oil Seal Replacer	B									*												*	TR			S	TR									S
	09223-46011	Crankshaft Front Oil Seal Replacer	B	*	*				*	*		*	*	S	*	*	*			S_1			*	G														

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																							
Part No.																																							
Illustration																																							
	**09223-50010**	Crankshaft Front Oil Seal Replacer	B			*				*							*	*	S																			S1
	**09223-56010**	Crankshaft Rear Oil Seal Replacer	B		*	*											*		*		*	*	*															
	09223-78010	Crankshaft Oil Seal Replacer	B										*				*							*														
	**09224-74010**	Engine Balancer Backlash Adjusting Tool	A																	S																		
	09226-10010	Crankshaft Front & Rear Bearing Replacer	B																	*						*	S			S2								
	09228-06501	Oil Filter Wrench	A	*				*												*																		
	09228-07501	Oil Filter Wrench	A						S1	*	*				*			S	*		*	*	*															
	09228-10002	Oil Filter Wrench	A		S	*							*	S1			*	*																				
	09228-22020	Oil Filter Wrench	A									*												S														
	**09228-34010**	Fuel Filter Wrench	A		S1									S									*															
	09228-64010	Fuel Filter Wrench	A		*	*							*	*			*	*																				

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT						
Classification / Part Name / Part No. / Illustration				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	09228-44011	Oil Filter Wrench	A		S				*			*		S_1				S_2	*					S_3													
	09228-64030	Fuel Filter Wrench	A			S																															
	**09229-55010**	Oil Cooler Relief Valve Wrench	B			S										*																					
	★ **09230-00010**	Radiator Service Tool Set	B	S	*	*		*	*	*				S_2		*	*	*	*	*	*		*		S_1													
	★ **09230-01010**	Radiator Service Tool Set	B	*	*	*		S_2	*		*	*	*	S_4	S_3		*		*	S_1	S_5	*	*	*													
	09231-14010	Punch	C	E							*	*	*		S_2		S_3		S_4	S_1	S_5	*															
	★ **09236-00101**	Water Pump Overhaul Tool Set	B	*	*	*	*	*	*			*	*	*		*	*		*					*													
	**09238-47012**	Water Pump Bearing Remover & Replacer	B																			*															
	09239-76010	Water Pump Rotor Puller	B				*																														
	★ **09240-00014**	Carburetor Adjusting Gauge Set	A	S				S	S			*						S	S S_1					S													
	★ **09240-00020**	Wire Gauge Set	A	S_2				S_4	S		S_5	*			*			S	S	S_3	*		*	S		*	*	S_1		*							
	★ **09241-76022**	Injection Pump Stand Set	C		*	*							*	*		*	*						*														
	**09243-00020**	Idle Adjusting Screw Wrench	A	S				S	*	*	S	S			*			S	S S_1	S	S_2	S			S													

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09243-00030	Idle Adjusting Screw Wrench	A																	S																	
	09245-54010	Injection Pump Stand Arm	C		*	*							*	*		*	*																				
	**09245-78010**	Injection Pump Stand Arm	C																				*														
	09248-05021	Valve Lifter Stopper	A	G				G		*	*					*			*	G	*	S	*														
	★ **09248-55040**	Valve Clearance Adjust Tool Set	A	*				*		*	*				*	*			*	G	*	S	*														
	★ **09248-55050**	Valve Clearance Adjust Tool Set	A			S			*																												
	09248-06020	Valve Lifter Stopper	A						*																												
	09248-64011	Valve Clearance Adjusting Tool	A			S1							*	S			*																				
	09249-63010	Torque Wrench Adaptor	A												*				*	S		*															
	★ **09250-10011**	Replacer Set "A"	B									*	*																		*						
	**09258-14010**	Air Pump Tester	A														S																				
	★ **09260-54012**	Injection Pump Tool Set	C		*	*							*	*		*	*																				
	★ **09260-58010**	Injection Pump Tool Set	C		*																																
	★ **09260-76020**	Injection Pump Tool Set	C				*																														

| Section | | | | MT | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09260-78010	Round Nut Wrench	C																					*														
	09260-78020	Screw Plug Wrench	C																					*														
	09263-00010	Boring Guide	C			*								*			S																					
	09268-17010	2 Spring Nozzle Tool Set	A														*																					
	09268-17020	Master Spring Seat	A		*												S																					
	★ **(09268-41045) 09268-41046**	Injection Measuring Tool Set	B	E				E	E	*	*				*		E	E	E	*	*	S	E															
	★ **(09268-45013) 09268-45014**	EFI Fuel Pressure Gauge	A	E				E	E	*	*				*			E	E	E	*	S	*		E													
	09268-46012	Nozzle Holder Body Wrench	A		*										S																							
	09268-46021	Nozzle Holder Retaining Nut Wrench	A		*										S																							
	★ **09268-64010**	Injection Nozzle Wrench Set	A		*	*								*	S		*	S_1																				
	★ **09268-74010**	Injector Remover	A								S_1								E	S	*																	
	09268-78010	Nozzle Retaining Nut Wrench	A																					*														
	★ **(09270-71010) 09270-71011**	Rocker Arm Support Tool Set	B																						*													
	**09275-17010**	Pre-stroke Measuring Adapter	A														*																					

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																						
Part No.																																						
Illustration																																						
	**09275-54011**	Plunger Stroke Measuring Tool	A		*	*						*	*		*	*																					
	09275-54020	Maximum Speed Adjusting Screw Lock Nut Wrench	A		S1								*		S																					
	09276-71010	Valve Lifter Tool	B									*												*												
	**09277-76010**	Automatic Timer Band Wrench	B				*																													
	09285-76010	Injection Pump Camshaft Bearing Cone Replacer	C	*	*	*	*	*	*	*	S	*	*	*	*		*	*	*	*	*	*	*	*	*												
	09286-46011	Injection Pump Spline Shaft Puller	C	*	*	*		*	*	*	S	*	*	*	*	*	*	*	*	*	*	*	*	*	*												
	**09286-76011**	Injection Pump Camshaft Bearing Cup Puller	C				*																	*													
	**09287-76010**	Injection Pump Camshaft End Play Micrometer	C				*																														
	**09288-46011**	Tappet Adjusting Gauge	C																					*													

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section / Classification / Part Name / Part No.	Illustration	ENGINE																				AT					MT						
		A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
09301-00110 Clutch Guide Tool		A	*							*																										
09301-00120 Clutch Guide Tool		A																																		
09301-00210 Clutch Guide Tool		A																*																		
09301-00220 Clutch Guide Tool		A																*																		
09302-20021 Clutch Diaphragm Spring Height No. 2 Gauge		B																																		
09302-25011 Clutch Pressure Lever Height Gauge		A																																		
09302-30031 Clutch Diaphragm Spring Height No. 3 Gauge		B																																		
09302-32010 Clutch Diaphragm Spring Height No. 5 Gauge		B																																		
09303-35011 Input Shaft Front Bearing Puller		A																																		
09303-55010 Input Shaft Front Bearing Puller		A																																		

| MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																					AT						MT						
Classification			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name / Part No. / Illustration																																					
	09304-12012	Input Shaft Front Bearing Replacer	A																					TR			S	TR									S
	09304-30012	Input Shaft Front Bearing Replacer	A																																		
	09304-47010	Input Shaft Front Bearing Replacer	A																																		
	09305-55020	Transmission Gear Shift Lever Remover	A																													*					
	09306-55020	Counter Gear Puller (for 5-Speed T/M)	B																													*					
	09307-12010	Extension Housing Bushing Replacer	B																											*			*	*	*		
	09308-00010	Oil Seal Puller	A																					* TR	*	*	*	S_5	*	*	*		*	*	*	*	* TR
	09308-14010	Replacer Pipe A	B																																		
	09308-14030	Replacer B	B																																		
	09308-10010	Oil Seal Puller	A		*							*				*							*	*	* TR	*	S_6	S TR	TR	S_5							* TR
	09308-55010	Oil Seal Puller	A																																		
	09309-14010	Remover & Replacer A	B																																		
	09309-14020	Remover & Replacer B	B																																		

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																				AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09309-14030	Remover & Replacer C	B																																		
	09309-14040	Remover & Replacer D	B																																		
	**09309-14050**	Remover & Replacer E	B																																		
	**09309-12020**	5th Driven Gear Replacer	B																												*	*					
	09309-32050	5th Driven Gear Replacer	B																															*		*	
	**09309-35010**	Transmission Rear Bearing Replacer	B																																		
	**09309-36010**	Transmission Rear Bearing Replacer	B																*		*										S1			*	*	*	
	★ **09309-36100**	Transmission Bearing Replacer Set	B																										TR								S
	09309-37010	Transmission Bearing Replacer	B	S				S2															*					S1									
	**09309-60010**	Extension Pipe	B																																		
	09310-14010	Stand	B																																		
	**09310-35010**	Countershaft Bearing Replacer	B																												*	*					S
	09310-36021	Countershaft Bearing Puller	B																																		
	09311-35020	Counter Gear Needle Roller Guide Shaft	B		*																			*													
	★ **09312-20011**	Transmission Gear Remover & Replacer	B																																		

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT						
Classification / Part Name / Part No. / Illustration				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	**09312-55010**	Idle Gear Puller (for 5-Speed T/M)	B																															*				
	**09315-00011**	Clutch Release Bearing Remover & Replacer	A																																			
	09315-00022	Clutch Release Bearing Remover & Replacer	A																																			
	09316-12010	Transfer Bearing Replacer	B																							*	S	TR	S_1									
	09316-20011	Transfer Bearing Replacer	B																						TR		S	TR	TR	*				*	*	*	*	TR
	★ **09316-60011**	Transmission & Transfer Bearing Replacer	B						*		*											*		*	TR	*	S	TR	TR	*	*		*	*	*	*	*	* TR
	09318-12010	Transfer Bearing Adujusting Nut Wrench	B																								S											
	**09318-20010**	Transfer Side Bearing Adjusting Nut Wrench	B																																*	*	*	
	**09319-60020**	Output Shaft Needle Roller Bearing Remover	B																										TR								S_2 S_1	S
	09320-89010	Transfer Clutch Spring Compressor	B																									S										
	09324-55011	Center Support Bearing Lock Nut Wrench	B																																			

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section / Classification / Part Name / Part No.	Illustration	ENGINE: A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	AT: A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	MT: C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F (4WD)	E15#F	E25#	G4#, 5#	Note
09325-12010		Transmission Oil Plug	A																								TR	TR									S	S: HILUX, 4RUNNER G40, 52, 58 S1: R150F, R141F, R151F S2: W56 (4WD)
09325-20010		Transmission Oil Plug	A						S13							*	S14							* TR	S4	S	S5 S10		*	S6				*	*	*	S15 S1 TR	S: A241H S1: 2WD S2: R44#, R45# S3: PR (22R-E) S4: A140E S5: A340E (2JZ-GE) S6: C50, 52 S7: SUPRA S8: W58 S9: PR (SC300) S10: A340F (1UZ-GE) S11: W55, W56 S12: PR (2JZ-GE M/T) S13: 2JZ-GE (SC400) S14: 3RZ-FE S15: G52, G53 G58
09325-40010		Transmission Oil Plug	A						S4																		S											S: A340E, A340F, A343F S1: R150 S2: PR (SC300) S3: PR (2JZ-GE M/T) S4: 2JZ-GE (SC400)
09326-20011		Output Shaft Bearing Lock Nut Wrench	B									*													*	S							*	*	*		S: A241H
09326-22011		Output Shaft Bearing Lock Nut Wrench	B																																			
★ **09330-00021**		Companion Flange Holding Tool	A	*	*	*		*	*	*	*	*	*	*	*	*	*	*	*	*	*		*	TR	*	*	S TR	TR	*								TR	S: A340H S1: PR (SC300) S2: FA (4WD) S3: TR (FZJ70, 73) S4: RA (KF series)
09330-50010		Propeller Shaft Center Bearing Replacer	B																																			S: PR (SC400)
★ **09332-25010**		Universal Joint Bearing Remover & Replacer	B																																			
09333-00013		Clutch Diaphragm Spring Aligner	B																																			S: CL (SC300)
09333-55011		Wrench 55 x 32 mm	B				*																															
09336-60010		Transmission Gear Remover	B																																			S: H55F
★ **09350-20015**		TOYOTA Automatic Transmission Tool Set	B																					*														S: FA (4WD)
★ **09350-30020**		TOYOTA Automatic Transmission Tool Set	B																					S		S2	*	*										S: A42D, A45DL, A43D, A46DE, A46DF S2: A244E

MODEL (MT): H14#F, 15#F	H4#, 5#	M15#	N4#	R14#, 15#	R24#, 25#, 44#, 45#	S5#	V160	W4#, 5#	STARLET	TERCEL / PASEO	SOLUNA	COROLLA 2WD	COROLLA 4WD	CORONA / CARINA	CELICA 2WD	CELICA 4WD	PICNIC	CAMRY	MR2	RAV4	SUPRA	AVALON	CROWN	ES300	GS300	SC300 / 400	LS400	LITEACE & TOWNACE	PREVIA 2WD	PREVIA 4WD	HIACE 2WD	HIACE 4WD	HILUX 2WD	HILUX 4WD	4 RUNNER	TACOMA	TOYOTA T100	DYNA 100	DYNA 150	DYNA 200, 250, 300, 350, 400	LAND CRUISER (L)	LAND CRUISER (H)	COASTER	H.D. TRUCK	TUV	M. CRUISER	Note
TR				S1				S2																									PR	PR													S: HILUX, 4RUNNER G40, 52, 58 S1: R150F, R141F, R151F S2: W56 (4WD)
			*		S2		S7	S1 TR S8 S11				PR		PR SR				PR	S12				S9		PR	PR	PR	PR	PR	S3	S3	PR			PR	PR							PR		S: A241H S1: 2WD S2: R44#, R45# S3: PR (22R-E) S4: A140E S5: A340E (2JZ-GE) S6: C50, 52 S7: SUPRA S8: W58 S9: PR (SC300) S10: A340F (1UZ-GE) S11: W55, W56 S12: PR (2JZ-GE M/T) S13: 2JZ-GE (SC400) S14: 3RZ-FE S15: G52, G53 G58
				S1			*	S												S3		PR		RA	S2 RA	RA					PR	PR			PR											S: A340E, A340F, A343F S1: R150 S2: PR (SC300) S3: PR (2JZ-GE M/T) S4: 2JZ-GE (SC400)
	*																																													S: A241H
			*																											FA																
* S3	TR	*		TR			*	TR				PR RA			PR RA				RA	PR RA		PR RA		RA	RA S1	RA BR	PR RA	RA PR	FA RA PR	PR RA FA			PR RA	PR FA RA	FA RA	FA RA	PR RA S2	RA	RA	PR RA	FA RA WI	FA RA WI	PR RA		S4	FA RA	S: A340H S1: PR (SC300) S2: FA (4WD) S3: TR (FZJ70, 73) S4: RA (KF series)
																				PR				PR	S	PR																					S: PR (SC400)
															PR												PR	PR	PR		PR	PR	PR		PR	PR	PR	PR	PR	PR	PR		PR	PR		
								CL	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL		CL			S		CL			CL		CL	CL	CL	CL	CL	CL	CL	CL	CL	CL		CL	CL	S: CL (SC300)
																																								BR SR DM						
*	S																																													S: H55F
																FA																		S	FA		S				FA						S: FA (4WD)
							*																																							S: A42D, A45DL, A43D, A46DE, A46DF S2: A244E

Section				ENGINE																				AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																						
Part No.																																						
Illustration																																						
	★ 09350-32014	TOYOTA Automatic Transmission Tool Set	B																							*	*	S		*	*	*						
	★ 09350-36010	TOYOTA Automatic Transmission Tool Set	B																									S	S1									
	09370-50010	Drive Line Angle Gauge	A																	*	*																	
	09495-65010 NEW	Axle Hub Stand	B																																			
	09495-65020 NEW	Axle Hub Set Nut Wrench	B																																			
	09495-65030 NEW	Axle Hub Lock Nut Wrench	B																																			
	09495-65040 NEW	Axle Hub Oil Seal Replacer	B																																			
	09496-65010 NEW	Top Cover Lock Nut Wrench	B																																			
	09496-65040 NEW	Top Cover Wrench	B																																			

MT										MODEL																																										Note
H14#F, 15#F	H4#, 5#	M15#	N4#	R14#, 15#	R24#, 25#, 44#, 45#	S5#	V160	W4#, 5#	STARLET	TERCEL / PASEO	SOLUNA	COROLLA 2WD	COROLLA 4WD	CORONA / CARINA	CELICA 2WD	CELICA 4WD	PICNIC	CAMRY	MR2	RAV4	SUPRA	AVALON	CROWN	ES300	GS300	SC300 / 400	LS400	LITEACE & TOWNACE	PREVIA 2WD	PREVIA 4WD	HIACE 2WD	HIACE 4WD	HILUX 2WD	HILUX 4WD	4 RUNNER	TACOMA	TOYOTA T100	DYNA 100	DYNA 150	DYNA 200, 250, 300, 350, 400	LAND CRUISER (L)	LAND CRUISER (H)	COASTER	H.D. TRUCK	TUV	M. CRUISER	
				*	*	*								FA				RA																														S: A340E, A340F
																																																S: A340E, A340F, A340H A343F S1: A443F
																					PR		PR		PR	PR	PR																					
																																														FA RA	
																																														FA RA	
																																														FA RA	
																																														SR	
																																														SR	

094

Section				ENGINE																					AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																						
Part No.																																						
Illustration																																						
	★ (09411-22011) 09411-22012	Side Gear Thrust Washer Adjust Tool	B																																			
	09502-12010	Differential Bearing Replacer	B																								S											
	09502-24010	Bearing Replacer	B																																			
	09504-00011	Differential Side Bearing Adjusting Nut Wrench	B																																			
	09504-22011	Differential Side Washer Remover & Replacer	B																																			
	09505-20010	Differential Side Bearing Replacer	B																																			
	09506-30012	Differential Drive Pinion Rear Bearing Cone Replacer	B																						TR									*	*	*	*	
	09506-35010	Differential Drive Pinion Rear Bearing Replacer	B		*																					*	S								*	*	*	*	*
	09509-25011	Rear Axle Bearing Lock Nut Wrench	A																																			
	09509-55042	Rear Wheel Bearing Nut Wrench	A																																			
	★ 09510-36010	Rear Hub & Drum Puller	A																																			
	★ 09510-55021	Rear Hub & Drum Puller	A																																			

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section / Classification / Part Name / Part No. / Illustration			ENGINE																			AT					MT						
			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	09513-36012	Rear Axle Bearing Lock Nut Wrench	A																																			
	**09513-36020**	Rear Axle Bearing Lock Nut Wrench	A																																			
	09513-36030	Rear Axle Bearing Lock Nut Wrench	A																																			
	09514-35011	Rear Wheel Bearing Puller	B																									TR									S
	09515-10010	Rear Axle Bearing Replacer	B																																			
	09515-21010	Rear Axle Shaft Bearing Replacer	B																																			
	09515-30010	Rear Wheel Bearing Replacer	B																						TR			TR										S
	09515-35010	Rear Wheel Bearing Replacer	B																																			
	09517-12010	Rear Axle Shaft Oil Seal Replacer	B																																			
	**09517-30010**	Rear Axle Shaft Oil Seal Replacer	B	*				S																														
	09517-36010	Rear Axle Shaft Oil Seal Replacer	B																									S1								S		
	09518-36020	Rear Axle Hub Oil Seal Replacer	B																																			
	★ **09520-00031**	Rear Axle Shaft Puller	A																																			

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section / Classification / Part Name / Part No.	Illustration	Part No.	Part Name	Classification	ENGINE																				AT					MT						
					A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
		★ 09520-10021	Drive Shaft Remover & Replacer	A																																			
		★ 09520-24010	Differential Side Gear Shaft Puller	A																																			
		★ 09520-32012	Differential Side Gear Shaft Puller	A																								S											
		★ 09520-32060	Drive Shaft Remover & Replacer	A																																			
		09521-24010	Drive Shaft Boot Clamping Tool	A																																			
		09521-25011	Rear Axle Shaft Puller	B																																			
		★ 09521-25020	Rear Axle Shaft Puller Attachment	B																																			
		09522-55010	Rear Shaft Guide Tool	A																																			
		09523-36010	Rear Axle Hub Guide Tool	B																																			
		09527-10011	Rear Axle Shaft Bearing Remover	B																				✻															
		09527-17011	Rear Axle Shaft Bearng Remover	B																																			✻
		09527-20011	Rear Axle Shaft Bearing Remover	B																																			
		09527-21011	Rear Axle Shaft Bearing Remover	B																																			
		09527-30010	Rear Axle Shaft Bearing Remover	B																									TR	TR									
		09528-55011	Differential Case Holder	B																																			

| Section / Classification / Part Name / Part No. | MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																				AT					MT						
Classification / Part Name / Part No. / Illustration			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	09530-55010	Differential Drive Pinion Adjusting Gauge	B																																			
	09550-00032	Replacer	B																						* TR			TR										S
	09550-00041	Replacer	B		*				*															*														
	★ **09550-10012**	Replacer Set "B"	B	*				G									*	S7	*	*		S3			TR			TR			*				*	*	*	S
	★ **09550-55011**	Differential Replacer Set	B																																			
	09550-60010	Differential Side Bearing Replacer	B																																			
	09554-14010	Differential Oil Seal Replacer	A																																			
	09554-22010	Differential Oil Seal Replacer	A																						TR			TR										TR
	09554-30011	Differential Oil Seal Replacer	A																						TR			TR										S
	09555-55010	Differential Drive Pinion Bearing Replacer	B																						TR		*	TR	TR						*			S
	**09556-22010**	Drive Pinion Front Bearing Remover	B																																			
	09556-30010	Drive Pinion Front Bearing Remover	B																																			
	**09564-32011**	Differential Preload Adaptor	B																							*	S				*	*						
	★ **09570-22011**	Differential Mounting Cushion Remover & Replacer	B																																			
	★ **09570-24010**	Differential Mounting Cushion Remover & Replacer	B																																			

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																					AT					MT						
Classification			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09571-50010 NEW	Differential Carrier Compressor	B																																		
	**09601-36021**	King Pin Bushing Remover & Replacer																																			
	**09601-37011**	King Pin Bushing Remover & Replacer	B																																		
	09601-55021	King Pin Bushing Remover & Replacer	B																																		
	09601-67010	King Pin Bushing Remover & Replacer	B																																	*	*
	09602-55010	Front Axle Inner Bearing Puller	B																																		
	09605-60010	Steering Knuckle Bearing Cup Replacer	B																																		
	**09606-60020**	Steering Knuckle Bearing Remover	B																																		
	**09607-60020**	Front Wheel Adjusting Nut Wrench	A																																		
	09608-00071	Drive Pinion Rear Bearing Cone Replacer	B																												S_1					
	09608-00081	Differential Side Bearing Cone Replacer	B																									TR	TR		*			S	*
	09608-03071	Replacer	B												*															*						
	09608-03081	Replacer	B								*																									
	09608-04031	Front Hub Inner Bearing Cone Replacer	B																																		
	09608-06031	Front Hub Inner Bearing Cone Replacer Attachment	B																																		

MT										MODEL																																						Note
H14#F, 15#F	H4#, 5#	M15#	N4#	R14#, 15#	R24#, 25#, 44#, 45#	S5#	V160	W4#, 5#		STARLET	TERCEL / PASEO	SOLUNA	COROLLA 2WD	COROLLA 4WD	CORONA / CARINA	CELICA 2WD	CELICA 4WD	PICNIC	CAMRY	MR2	RAV4	SUPRA	AVALON	CROWN	ES300	GS300	SC300 / 400	LS400	LITEACE & TOWNACE	PREVIA 2WD	PREVIA 4WD	HIACE 2WD	HIACE 4WD	HILUX 2WD	HILUX 4WD	4 RUNNER	TACOMA	TOYOTA T100	DYNA 100	DYNA 150	DYNA 200, 250, 300, 350, 400	LAND CRUISER (L)	LAND CRUISER (H)	COASTER	H.D. TRUCK	TUV	M. CRUISER	
																												RA																				
																																							FA								
																																							FA	S							S: FA (Ex. 4 ton models)
																																												FA RA			
	*																																													
																																												FA			
																FA	FA																								FA	FA				
																																									FA	FA				
																															FA	FA					S				FA	FA				S: FA (4WD)
						*															PR				PR	S	PR																			S: PR (SC400) S_1: C141, C150, C151
TR		*			*																RA																									S: E153
																								*																						
											SR										RA SR		SR		SR	S						S_1	S_1	BR SR	SR	SR	S_1	S_1	BR	BR SR	BR SR				BR	S: SR (SC300) S_1: SR (w/PS)
																									PR																					

Section / Classification / Part Name / Part No.	Illustration	ENGINE																				AT					MT							
		A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F (4WD)	E15#F	E25#	G4#, 5#
09608-06041 Front Hub Inner Bearing Cone Replacer	B		*																*																	
09608-10010 Steering Knuckle Oil Seal Replacer	B																																			
09608-12020 Front Hub & Drive Pinion Bearing Replacer Set	B																*					*														
09608-16011 Rear Hub Bearing Tool	B																											S								
★ **(09608-16041) 09608-16042** Front Hub Bearing Adjusting Tool	B																																			
09608-30012 Front Hub & Drive Pinion Bearing Tool Set	B																S																			
09608-30030 Differential Drive Pinion Front Bearing Cup Remover	B																																			
09608-32010 Steering Knuckle Oil Seal Replacer	B																								S_3	S	S_1		*							
09610-20012 Pitman Arm Puller	A																							*			S_2									
09610-55012 Pitman Arm Puller	B																																			

| MT | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification / Part Name / Part No. / Illustration				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	09610-55020	Pitman Arm Puller	A																																		
	**09611-12010**	Tie Rod End Puller	A																																		
	09611-20015	Tie Rod End Puller	A																																		
	09611-22012	Tie Rod End Puller	A																																		
	09611-36020	Tie Rod End Puller	A																																		
	★ **09612-00012**	Rack & Pinion Steering Rack Housing Stand	B																																		
	09612-07010	Mainshaft Retaining Ring Remover & Replacer	C																																		
	★ **09612-10093**	Steering Gear Housing Overhaul Tool Set	B																																		
	**09612-22011**	Tilt Handle Bearing Replacer	B								✻																			✻	✻						
	★ **09612-24014**	Steering Gear Housing Overhaul Tool Set	B			✻		S			✻									S3	✻	S2						TR	TR								
	★ **09612-30012**	Steering Worm Bearing Puller	B																																		S
	★ **09612-55010**	Steering Gear Housing Overhaul Tool Set	B																																		

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																					AT					MT						
Classification			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	★ 09612-65014	Steering Worm Bearing Puller	B																					TR		S	TR		S6	*	*		*	*	*	*	TR
	09613-12010	Power Steering Control Valve Puller	B																																		
	09613-12020	Control Valve Lock Nut Wrench	B																																		
	09613-26010	Steering Worm Bearing Cone Remover	B																																		
	09616-00010	Steering Worm Bearing Adjusting Socket	B																																		

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																				AT					MT						
Classification / Part Name / Part No. / Illustration				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	09617-30030	Worm Bearing Adjusting Screw Lock Nut Wrench	B																																		
	09617-30040	Worm Bearing Adusting Screw Lock Nut Wrench	B																																		
	09617-60010	Worm Bearing Adjusting Screw Lock Nut Wrench	B																																		
	09618-60010	Front Axle & Drive Shaft Bearing Replacer	B																																		
	09623-30011	Steering Worm Bearing & Oil Seal Replacer	B												*				*		*		S_5								*			S	*	*	*
	09628-10011	Ball Joint Puller	A																																		
	09628-12022	Ball Joint Puller	A																																		
	09628-30011	Ball Joint Remover	A																																		

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																					AT					MT						
Classification / Part Name / Part No. / Illustration			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F (4WD)	E15#F	E25#	G4#, 5#
	**09628-62011**	Ball Joint Puller	A																								S				*						
	★ **09630-00014**	Power Steering Gear Housing Overhaul Tool Set	B																																		
	★ **09630-24014**	Steering Rack Oil Seal Tool Set	B																																	S3	
	**09631-00350**	Steering Rack Cover 35	B																																		
	09631-10010	Steering Rack Replacer "D"	B																																		
	09631-10021	Rack Stopper Wrench	B																																		
	**09631-10030**	Oil Seal Remover	B																		S4																
	09631-10041	Stering Rack Cover "D"	B																																		
	09631-12031	Oil Seal "A" Remover	B																																		
	★ **09631-12071**	Steering Rack Oil Seal Test Tool	B																																		
	09631-16010	Cylinder End Stopper Nut Wrench	B																																		
	09631-16020	Steering Rack Cover "A"	B																																		
	09631-20031	Oil Seal "B" Remover	B					*																													

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																				AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																			
Part No.																																			
Illustration																																			
	09631-20040	Oil Seal "B" Replacer	B																							A13#, 14#: S_2											
	**09631-20051**	Steering Rack Cover "C"	B																																		
	**09631-20060**	Bearing Guide Nut Wrench	B																																		
	09631-20070	Seal Ring Guide	B																																		
	09631-20081	Seal Ring Tool	B																																		
	09631-20090	Cylinder End Stopper Nut Wrench	B																																		
	09631-20102	Steering Rack Cover "H"	B																																		
	09631-20111	Steering Rack Cover "G"	B																																		
	09631-20120	Cylinder End Stopper Nut Wrench	B																																		
	**09631-22020**	Power Steering Hose Nut 14 x 17 mm Wrench Set	A	*			*	*	*	*			*		*	*	*	*	S_2	*		*															
	★ **09631-22030**	Steering Rack Oil Seal Test Tool	B																																		
	09631-22040	Oil Seal "C" Remover	B																																		

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																					AT					MT						
Classification			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09631-22060	Bearing Guide Nut Wrench	B																																		
	09631-22070	Oil Seal Replacer	B																																		
	09631-32010	Oil Seal Replacer	B																																		
	09631-32020	Seal Ring Tool	B																																		
	09631-33010	Steering Rack Cover "I"	B																																		
	**09632-36010**	Steering Vane Pump Bearing Replacer	B																																		
	**09633-00020**	Power Steering Hose Nut Wrench (12 mm)	A																																		
	**09634-60013**	Steering Knuckle Centering Gauge	B																																		
	09636-20010	Upper Ball Joint Dust Cover Replacer	B					*									*													S_1						
	★ **09640-10010**	Power Steering Pressure Gauge Set	A																																		
	**09642-00010**	Attachment	A																																		
	**09642-00020**	Attachment	A																																		
	09649-17010	Steering Knuckle Tool	B																																		
	**09650-17011**	Hub Bolt Remover	A																																		

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09702-55021	Brake Adjusting Wrench "B"	A																																		
	09703-30010	Brake Shoe Return Spring Tool	A																																		
	09704-10010	Brake Adjusting Tool	A																																		
	09704-30010	Brake Adjusting Tool	A																																		
	09705-55050	Spring U Bolt Nut Wrench	B																																		
	09707-37010	Spring Bushing Remover & Replacer	B																																		
	★ 09709-29018	LSPV Gauge Set	C																																		
	09709-55010	Brake Pressure Gauge Set	C																																		
	09710-02021	Handle	B	*					*																												
	09710-02031	Bar	B															*																			
	09710-04081 NEW	Base	B																																		
	★ 09710-14013	Rear Suspension Bushing Tool Set	B																																		
	★ 09710-20011	Front Suspension Bushing Tool Set	B																																		
	★ 09710-22021	Front Suspension Bushing Tool Set	B																																		

MT										MODEL																																						Note
H14#F, 15#F	H4#, 5#	M15#	N4#	R14#, 15#	R24#, 25#, 44#, 45#	S5#	V160	W4#, 5#	STARLET	TERCEL / PASEO	SOLUNA	COROLLA 2WD	COROLLA 4WD	CORONA / CARINA ℰ	CELICA 2WD	CELICA 4WD	PICNIC	CAMRY	MR2	RAV4	SUPRA	AVALON	CROWN	ES300	GS300	SC300 / 400	LS400	LITEACE & TOWNACE	PREVIA 2WD	PREVIA 4WD	HIACE 2WD	HIACE 4WD	HILUX 2WD	HILUX 4WD	4 RUNNER	TACOMA	TOYOTA T100	DYNA 100	DYNA 150	DYNA 200, 250, 300, 350, 400	LAND CRUISER (L)	LAND CRUISER (H)	COASTER	H.D. TRUCK	TUV	M. CRUISER	
																																											BR			
												BR	BR	BR	BR	BR	BR		BR			BR					BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	
									BR																																						
																																											BR	BR		
																																											FA RA			
																																							S				FA			S: RA (WU series)
									BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR		BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR	BR		BR	BR	
																																											BR			
																		FA			FA		FA																								
															FA			RA		FA							FA S																				S: RA (4-Link)
																												RA	RA	FA																	
															RA					RA										FA	FA									RA	RA	RA					

Section				ENGINE																					AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																						
Part No.																																						
Illustration																																						
	★ 09710-22042	Rear Suspension Bushing Tool Set	B																																			
	★ 09710-26011	Front Suspension Bushing Tool Set	B																																			
	★ (09710-28011) 09710-28012	Front Suspension Bushing Tool Set	B																																			
	★ (09710-28020) 09710-28021	Front Suspension Bushing Tool Set	B																							*												
	★ 09710-30021	Suspension Bushing Tool Set	B																																			
	★ (09710-30030) 09710-30031	Rear Suspension Bushing Tool Set	B																								S											
	★ 09710-30041	Rear Suspension Bushing Tool Set	B																																			
	09710-30050	Suspension Arm Bushing Replacer	B																																			
	09710-30055	Suspension Arm Bushing Remover	B																																			
	09717-20010	Brake Stop Return Spring Remover	A															*																				
	09718-00010	Shoe Hold Down Spring Driver	A																																			
	09718-20010	Brake Shoe Return Spring Replacer	A															*																				
	09718-55010	Shoe Hold Down Spring Driver	A																																			
	★ 09719-14020	Rear Disc Brake Tool Set	A																																			
	★ 09720-00013	Shock Absorber Overhaul Tool Set	B																																			

| Section | MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section / Classification / Part Name / Part No.	Illustration			ENGINE																					AT					MT							
				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
		★ **09726-10011**	Lower Suspension Arm Bushing Remover & Replacer	B																																		
		★ **09726-12023**	Lower Suspension Arm Bushing Remover & Replacer	B																																		
		★ **09726-27012**	Front Suspension Arm Bushing Remover & Replacer	B																																		
		★ **09726-35011**	Front Lower Arm Bushing Remover & Replacer	B																																		
		09726-36010	Lower Control Arm Bushing Replacer	B																																		
		09726-40010	Lower Control Shaft Bearing Replacer	B																																		
		09727-00050	Arm Set "B"	B																																		
		**09727-00060 NEW**	Arm Set "C"	C																																		
		★ **09727-22011**	Front Spring Compressor	B																																		
		★ **09727-30021**	Coil Spring Compressor	B																																		
		**09729-22031**	Front Spring Upper Seat Holder	B																																		
		09736-27010	Booster Diaphragm Remover & Replacer	B																																		

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																						
Part No.																																						
Illustration																																						
	**09737-00010**	Brake Booster Push Rod Gauge	A																																			
	09751-36011	Brake Line Union Nut 10 x 12 mm Wrench	A																																			
	★ **09753-00013**	Brake Booster Overhaul Tool Set	B																																			
	09753-30011	Reaction Disc Hub Holding Tool	B																																			
	09753-30020	Oil Seal Replacer	B																																			
	09753-30040	Reaction Disc Hub Lock Nut Wrench	B																																			
	09753-40010	Base Plate	B																																			
	09756-00010	Adjusting Bolt Guide Nut	B																																			

| MT | | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																						AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																						
Part No.																																						
Illustration																																						
	★ 09804-24010	Luggage Compartment Door Torsion Bar Tool	C																																			
	09806-30010	Windshield Moulding Remover	C																																			
	09808-14010	Fuel Sender Gauge Tool Assy	C								*																											
	09810-38140	Nut Wrench Starter Magent Switch 14	C	*		*		*	*	*	S	*	*	*	*	*		*	*	*	*	*	*	*	*													
	09810-38170	Nut Wrench Starter Magent Switch 17	C		*		*						*	*			*																					
	09812-00010	Door Hinge Set Bolt Wrench	C			S																																
	09812-00020	Door Hinge Set Bolt Wrench	C			S																																
	09814-22010	Rear Wiper Pivot Shaft Lock Nut Wrench	A																	S	*																	
	09816-30010	Oil Pressure Switch Socket	B	S_1	*			*	*		*	*		S_3	*	*			*	S		S_2	*															
	09817-16011	Back-up Light Switch Tool	A												*					S	*	S_3							TR		*	*		*		S_2		S_1
	09817-33190 NEW	Sensor Socket Wrench	B																	S																		
	★ 09820-00021	Alternator Rear Bearing Puller	B	*	*	*		*	*	*	S		*	*	*	*	*	*	*	*	*	*	*	*														
	09820-00030	Alternator Rear Bearing Replacer	B	S_1	*	*		*	*	*	S_2	*	*	S_3	*	*	*	*	*	S	*	*	*															
	★ 09820-63010	Alternator Pulley Set Nut Wrench Set	B	*	*	S_1		*	*	*	S_2	*	*	*	*	*	*	*	*	*	*	*	*		*													
	09830-36010	Front Mounting Cushion Remover & Replacer	C												*																							

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09841-56010	Alternator Stand	C				*																														
	09842-14010	EFI Idle Adusting Wire Harness	A																					S													
	**09842-30020**	Wire "C" EFI Inspection	B																					S													
	09842-30040	Wire "D" EFI Inspection	B																	S																	
	09842-30050	Wire "A" EFI Inspection	B	E				E										E	E	E			*	E													
	09842-30055	Wire "G" EFI Inspection	B	S						*											*	*	G														
	09842-30060	Wire "E" EFI Inspection	B								S_2									S				S_1														
	09842-30070	Wire "F" EFI Inspection	B	*				E	E	*	*				*			E	E	S	*		*														
	09843-18020	Diagnosis Check Wire	A	*				*	*		*		*		*			*	*	*	*	*	*			S	*	*	*	*	S							
	09843-18030 NEW	Tocho-pulse Pickup Wire No. 2	A												S															S_2								
	09843-18040 NEW	Diagnosis Check Wire No.2	A												S															S_1								

| Section | MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section / Classification / Part Name / Part No. / Illustration		ENGINE																				AT					MT						
		A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
	★ 09910-00015 Puller Set	B																												S2		*		*	*	*	
	09921-00010 Spring Tension Tool	A																						* TR	*	*	* TR	* TR	*	*	*		*	*	*		* TR
	09922-00010 Wrench 5 x 12 mm	B														S	S						S														S1
	09922-10010 Variable Open Wrench	A																								S											
	09950-00020 Bearing Remover	B		S5							*	S7								*				TR	*	*	TR	TR	*	*	*		*	*	*	*	* S
	09950-00030 Bearing Remover Attachment	B																							S1	S	TR	TR	*	*	*		*		S2	*	
	★ 09950-30010 Puller A set	A																												S3	S4		*	*	*	*	
	★ 09950-40010 Puller B set	A		*	*	*		*		S7	*	*	S12		*	*	*	*	*	*			*	*	TR	*	S10 S3	TR	TR	*	S9 *	*		*	*	S1	*	* S2
	★ 09950-50010 Puller C set	A	S	*	*	*	*	*	*	*	*	*	*	*	*	*	S1	*	*		*	*	*	*	TR													*
	★ 09950-60010 Replacer Set	B	*	*	*		*	*		S3	*	*	S9	S1		*		*	*	*	*	*			TR	S4	S5	* TR	TR S6		*	*				S8	*	S7 TR

| MODEL | | | | | | | | | | | | | | | | | | |

Section			ENGINE																					AT						MT						
Classification / Part Name / Part No. / Illustration			A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F (4WD)	E15#F	E25#	G4#, 5#
	★ 09950-60020 NEW	Replacer Set	B												*										TR			TR			*	*					*	TR
	★ 09950-70010	Handle Set	B	*	*	*			*		*	*		S1	*		*		*	*		*	*		TR	S2	S5	* TR	TR	*	*	*				S3	*	TR S4
	★ 09960-10010	Variable Pin Wrench Set	A	S5	*	*			*		*	*	*	*	*	*	*		*	*	*	*	*	*			S3										
	★ 09990-00150	ABS Actuator Checker and Sub-harness	C																																		
	09990-00163	ABS Actuator Checker Sheet "A"	C																																		
	09990-00175	ABS Actuator Checker Sub-harness "B"	C																																		
	09990-00200	ABS Actuator Checker Sub-harness "C"	C																																		
	09990-00205	ABS Actuator Checker Sub-harness "D"	C																																		
	09990-00210	ABS Actuator Checker Sub-harness "E"	C																																		
	09990-00250	ABS Actuator Checker Sub-harness "G"	C																																		
	09990-00260	ABS Actuator Checker Sub-harness "B1"	C																																		
	09990-00280	ABS Actuator Checker Sub-harness "H"	C																																		
	09990-00300	ABS Actuator Checker Sub-harness "I"	C																																		

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																					AT					MT							
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																					
Part No.																																					
Illustration																																					
	09990-00310	ABS Actuator Checker Sub-harness "J"	C																																		
	09990-00330	TRC Actuator Air Bleed Wire	C																																		
	09990-00360	ABS Actuator Checker Sub-harness "L"	C																																		
	09990-00370	ABS Actuator Checker Sheet "L"	C																																		
	09990-00400 NEW	ABS Actuator Checker Sheet "M"	C																																		
	09990-00410 NEW	ABS Actuator Checker Sheet "N"	C																																		
	09990-00420 NEW	ABS Actuator Checker Sheet "O"	C																																		
	09990-00430 NEW	ABS Actuator Checker Sheet "P"	C																																		
	09990-00440 NEW	ABS Actuator Checker Sub-harness "O"	C																																		
	09990-00450 NEW	ABS Actuator Checker Sub-harness "P"																																			
	09990-01000	Check Harness "A" Engine Control Computer	A								S											*						S1									
	★ **(09992-00024) 09992-00025**	Cylinder Compression Check Gauge Set	A		*	*						*	*	*	*			*	*			*			*													
	★ **(09992-00094) 09992-00095**	Automatic Transmission Oil Pressure Gauge Set	A																							*	*	*	*	*	*							
	★ **(09992-00241) 09992-00242**	Turbocharger Pressure Gauge	C	*		S6					S3		*	S1		S			S2	S4																	

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |

Section				ENGINE																				AT					MT						
Classification				A series	B series	C series	D series	E series	FZ series	G series	JZ series	K series	KZ series	L series	MZ series	N series	HZ, HD series	R series	RZ series	S series	TZ series	UZ series	VZ series	W series	Y series	A4#	A13#, 14#	A24#	A34#, 35#	A44#	A54#	C4#, 5#	C14#, 15#	D5#	E5# (2WD)	E5#F# (4WD)	E15#F	E25#	G4#, 5#
Part Name																																			
Part No.																																			
Illustration																																			
	09992-00350 NEW	Brake Reservoir Pressure Adapter	A																																
	**09992-00400**	Attachment No. 7	A		*												S																		
	**09992-00500 NEW**	Compression Gauge Attachment	A										*																						

| MT | | | | | | | | | MODEL | | | | | | | | | | | | | | | | | | |