

All Models








Tools / Consumables / Personal Protection Equipment &
Symbols Description

Master



Latest Version
SCAN HERE

































SYMBOLS EXPLANATION

 <p> EN Correct DE Richtig ES Correcto FR Correct IT Guisto PT Correcto NL Correct DA Rigtigt NO Riktig SV Rätt FI Oikein CS Správně HU Helyes PL Prawidłowo EL Σωστό RU Правильно TR Doğru BG вярно EE Õige LV Pareizi LT Teisingai RO Corect SI Pravilno SK Správne </p>	 <p> EN Incorrect DE Falsch ES Incorrecto FR Incorrect IT Errato PT Incorreto NL Niet correct DA Ukorrekt NO Stemmer ikke SV Felaktig FI Väärä CS Nesprávný HU Helytelen PL Niepoprawnie EL Λάθος RU Неправильно TR Yanlış BG Неправилно EE Vale LV Nepareizi LT Teisingai RO Incorect SI Napačno SK Nesprávne </p>	 <p> EN Position arrow DE Positionspfeil ES Flecha de posición FR Flèche de positionnement IT Freccia di posizione PT Seta de posição NL Positie pijl DA Positionspil NO Posisjonspil SV Positionspil FI Sijoitusnuoli CS Šipka polohy HU Strípka положення PL Strzałka pozycji EL Τοποθέτηση βέλους RU Стрелка положения TR Konum oku BG Стрелка за позиция EE Positsiooninool LV Pozīcijas bultiņa LT Padėties rodyklė RO Săgeată de poziție SI Pozicijska puščica SK Polohovacia šípka </p>	 <p> EN Movement arrow DE Bewegungspfeil ES Flecha de movimiento FR Flèche de mouvement IT Freccia di movimento PT Seta de movimento NL Beweging pijl DA Bevægelse pil NO Bevegelsespil SV Rörelsepil FI Liike nuoli CS Šipka pohybu HU Mozgás nyíl PL Strzałka kierunku EL Βέλος κίνησης RU Стрелка движения TR Hareket oku BG Стрелка за движение EE Liikumise nool LV kustības bultiņa LT Judėjimo rodyklė RO Săgeată de mișcare SI Puščica za gibanje SK Šípka pohybu </p>	 <p> EN Partial removal DE Teilentfernung ES Eliminación parcial FR Désassemblage partiel IT Rimozione parziale PT Remoção parcial NL Gedeeltelijke verwijdering DA Delvis fjernelse NO Delvis fjerning SV Partiell borttagning FI Osittainen poisto CS Částečné odstranění HU Részleges eltávolítás PL Częściowe usunięcie EL Μερική αφαίρεση RU Частичное удаление TR Kısmi kaldırma BG Частично премахване EE Osaline eemaldamine LV Daļēja noņemšana LT Dalinis pašalinimas RO Îndepărtarea parțială SI Delna odstranitev SK Čiastočné odstránenie </p>	 <p> EN Turn part DE Teil drehen ES Girar la pieza FR Retourner la pièce IT Gira parte PT Parte de volta NL Draai deel DA Vend del NO Snu en del SV Vänd del FI Käännä osa CS Otočte část HU Fordítsa alkatrészt PL Rotacja EL Γυρίστε μέρος RU Поверните часть TR Parçayı çevir BG Обърнете част EE Pöörake osa LV Pagrieziet daļu LT Pasukite dalį RO Rotiți partea SI Obrnite del SK Otočte časť </p>
 <p> EN Disconnect DE Trennen ES Desconectar FR Déconnecter IT Disconnetti PT Desconectar NL Verbinding verbreken DA Koble fra NO Koble fra SV Koppla ifrån FI Katkaista CS Odpojit HU Leválasztás PL Rozłączyć się EL Αποσυνδέω RU Отключить TR Bağlantıyı kes BG Прекъснете връзката EE Katkesta ühendus LV Atvienot LT Atsijungti RO Deconectat SI Prekinii povezavo SK Odpojit </p>	 <p> EN Connect DE Anschließen ES Conectar FR Connecter IT Collegare PT Conectar NL Aansluiten DA Opret forbindelse NO Koble SV Ansluta FI Kytkeä CS Připojit HU Csatlakozás PL Połączyć EL Συνδέω-συνδεομαι RU Соединять TR Bağlamak BG Свържете се EE Ühendage LV Savienot LT Prijsijungti RO Conectați SI Povežite se SK Pripojte sa </p>	 <p> EN Disconnect fluid DE Flüssigkeit trennen ES Desconecte el fluido FR Déconnecter tuyaux IT Scollegare il fluido PT Desconecte o fluido NL Vloeistof loskoppelen DA Frakobl væsken NO Koble fra væsken SV Koppla bort vätskan FI Irrota neste CS Odpojte kapalinu HU Kösse le a folyadékot PL Odłączyć płyn EL Αποσυνδέστε το υγρό RU Отсоедините жидкость TR Sivi bağlantısını kesin BG Изключете течността EE Ühendage vedelik lahti LV Atvienojiet šķidrumu LT Atjunkite skystį RO Deconectați lichidul SI Odklopite tekočino SK Odpojte kvapalinu </p>	 <p> EN Connect fluid DE Flüssigkeit anschließen ES Conectar fluido FR Connecter tuyaux IT Collegare il fluido PT Conecte o fluido NL Vloeistof aansluiten DA Tilslut væske NO Koble til væske SV Anslut vätska FI Liitä neste CS Připojte kapalinu HU Csatlakoztassa a folyadékot PL Podłączyć płyn EL Συνδέστε το υγρό RU Подключить жидкость TR Sıvıyı bağlayın BG Свържете течността EE Ühendage vedelik LV Pievienojiet šķidrumu LT Prijunkite skystį RO Conectați fluidul SI Priključite tekočino SK Pripojte kvapalinu </p>	 <p> EN Airbag DE Airbag ES Bolsa de airbag FR Airbag IT Airbag PT Airbag NL Airbag DA Airbag NO Airbag SV Krockkudde FI Airbag CS Airbag HU Légzsák PL Poduszka powietrzna EL Αερόσακός RU Воздушная подушка TR Hava yastığı BG Въздушна възглавница EE Turvapadi LV Gaisa spilvens LT Oro pagalvė RO Airbag SI Zračna blazina SK Airbag </p>	
 <p> EN Information DE Information ES Información FR Information IT Informazione PT Em formação NL Informatie DA Information NO Informasjon SV Information FI Tiedot CS Informace HU Információ PL Informacja EL Πληροφορίες RU Информация TR Bilgi BG Информация EE Teave LV Informācija LT Informacija RO Informație SI Informacije SK Informácie </p>	 <p> EN See reference DE Siehe Referenz ES Ver referencia FR Voir référence IT Vedi riferimento PT Ver referência NL Zie referentie DA Se reference NO Se referanse SV Se referens FI Katso viite CS Viz odkaz HU Lásd a hivatkozást PL Zobacz referencję EL Βλέπε παραπομπή RU См. ссылку TR Referansa bakın BG Вижте справка EE Vaata viidet LV Skatīt atsauci LT Žr. nuorodą RO Vezi referința SI Glej referenco SK Pozri referenciu </p>	 <p> EN Look/See DE Schau ES Ver FR Regarder IT Guarda PT Olhar/Ver NL Kijk zie DA Se NO Se SV Titta/se FI Katso CS Podívejte se/vidíte HU Nézd/Lásd PL Spójrz/Zobacz EL Κοίτα δεξ RU Смотриеть видеть TR Bak/Gör BG Вижте EE Vaata LV Skaties/redzi LT Pažiūrėk RO Uite/Vezi SI Pogledj/glej SK Pozri </p>	 <p> EN Warning DE Warnung ES Advertencia FR Avertissement IT Avvertimento PT Aviso NL Waarschuwing DA Advarsel NO Advarsel SV Varning FI Varoitus CS Varování HU Figyelem PL Ostrzeżenie EL Προειδοποίηση RU Предупреждение TR Uyarı BG Внимание EE Hoiaatus LV Brīdinājums LT Įspėjimas RO Avertizare SI Opozorilo SK Pozor </p>	 <p> EN Safety critical DE Sicherheitskritisch ES Seguridad crítica FR Sécurité critique IT Sicurezza critica PT Segurança crítica NL Cruciaal voor de veiligheid DA Sikkerhed kritisk NO Sikkerhet kritisk SV Säkerhet kritisk FI Turvallisuukskriittinen CS Bezpečnost kritická HU Biztonság kritikus PL Operacja krytyczna bezpieczeństwa EL Η ασφάλεια είναι κρίσιμη RU Критическая безопасность TR Emniyet açısından kritik BG Критично за безопасността EE Ohutuskiitiline LV Drošībai kritiski svarīgi LT Saugumas kritinis RO Siguranța critică SI Varnost kritična SK Bezpečnosť' kritická </p>	

SYMBOLS EXPLANATION

 <p>EN Don't touch DE Nicht berühren ES No tocar FR Ne touchez pas IT Non toccare PT Não toque NL niet aanraken DA rør ikke NO ikke rør SV Rör inte FI Älä koske CS Nedotýkejte se HU Ne érintse meg PL Nie dotykaj EL Μην αγγίζετε RU Не трогай TR dokunma BG Не докосвайте EE Ärge puudutage LV Neaiztiēciet LT Nelieskite RO nu atinge SI Ne dotikajte se SK Nedotýkajte sa</p>	 <p>EN Hand tighten DE Handfest anziehen ES Apretar con la mano FR Serrer à la main IT Stringere a mano PT Apertar com a mão NL Handvast aandraaien DA Stram med hånden NO Stram for hånd SV Dra åt för hand FI Kiristää käsin CS Utáhněte rukou HU Kézzel húzza meg PL Dokręcić ręcznie EL Σφίξτε το χέρι RU Затянуть вручную TR Elle sıkın BG Затегнете с ръка EE Pingutage käsitsi LV Pievelciet roku LT Ranka priveržkite RO Strângeți cu mâna SI Ročno zategnite SK Dotiahnite rukou</p>	 <p>EN Centre line DE Mittellinie ES Línea central FR Ligne médiane IT Linea centrale PT Linha central NL Middenlijn DA Midterlinje NO Midtlinje SV Mittlinje FI Keskilinja CS Středová čára HU Középvonal PL Linia środkowa EL Κεντρική γραμμή RU Центральная линия TR Merkez hattı BG Централна линия EE Keskkjoon LV Centra līnija LT Centrinė linija RO Linia centrală SI Sredinska črta SK Stredová čiara</p>	 <p>EN 2 Person operation DE 2-Personen-Betrieb ES Operación a 2 personas FR Fonctionnement à 2 personnes IT Operazione a 2 persone PT Operação de 2 pessoas NL Bediening voor 2 personen DA 2 Persons betjening NO 2 Person drift SV 2 personers drift FI 2 henkilön toiminta CS Obsluha 2 osobami HU 2 személyes működtetés PL Obsługa 2 osób EL Λειτουργία 2 ατόμων RU 2 человека операции TR 2 kişilik operasyon BG Операция на 2 човека EE 2 inimese operatsioon LV 2 Personas darbība LT 2 asmenų operacija RO Operare cu 2 persoane SI Delovanje 2 oseb SK Obsluha 2 osobami</p>	 <p>EN Throw away / Recycle DE Wegschmeißen / Recyclen ES Tirar a la basura / Reciclar FR Jeter / Recycler IT Buttar via / Ricicla PT Jogar fora / Reciclagem NL Weggoeien / Recyclen DA Smid væk / Genbrug NO Kast / Resirkulering SV Kasta iväg / Återvinna FI Heittää pois / Kierrättää CS Zahodit / Recyklovat HU Dobd el / Újrahasznosít PL Wyrzucić / Recykling EL Πετάω / Ανακυκλώνω RU Выбросить / Рециркулировать TR Atmak / Geri dönmüşüm BG Изхвърлям / Рециклиране EE Viska minema / Taaskasutada LV Izmetiet / Pārstrādāt LT Išmesti / Perdirbti RO Arunca / Reciclează SI Vrzi stran / Recikliraj SK Zahodit' / Recyklovat'</p>
 <p>EN Vehicle direction DE Fahrzeugrichtung ES Dirección del vehículo FR Sens du véhicule IT Direzione del veicolo PT Direção do veículo NL Voertuig richting DA Køretøjets retning NO Kjøretøy retning SV Fordonets riktning FI Ajoneuvon suunta CS Směr vozidla HU A jármű iránya PL Kierunek pojazdu EL Κατεύθυνση οχήματος RU Направление автомобиля TR Araç yönü BG Посоката на превозното средство EE Sõiduki suund LV Transportlīdzekļa virziens LT Transporto priemonės kryptis RO Direcția vehiculului SI Smer vozila SK Smer vozidla</p>	 <p>EN LHD/RHD drive DE LHD/RHD-Antrieb ES Unidad LHD/RHD conducción FR Conduite à gauche/conduite à droite IT Guida a sinistra/destra PT Unidade LHD/RHD NL LHD/RHD-aandrijving DA LHD/RHD drev NO LHD/RHD-stasjon SV LHD/RHD-enhet FI LHD/RHD-aseama CS Pohon LHD/RHD HU LHD/RHD meghajtó PL Kierownica LHD RHD EL Μονάδα δίσκου LHD/RHD RU леворульный/правосторонний привод TR LHD/RHD sürücü BG LHD/RHD задвижване EE LHD/RHD draiv LV LHD/RHD disks LT LHD/RHD diskas RO Unitate LHD/RHD SI LHD/RHD pogon SK Pohon LHD/RHD</p>	 <p>EN Earth connection DE Masseanschluss ES Conexión a tierra FR Connexion à la terre IT Collegamento a terra PT Conexão à terra NL Aardverbinding DA Jordforbindelse NO Jordforbindelse SV Jordanslutning FI Maaliitântä CS Zemní spojení HU Föld csatlakozás PL Masa EL Σύνδεση γείωσης RU Заземление TR Dünya bağlantısı BG Земна връзка EE Maandusühendus LV Zemes savienojums LT Įžeminimo jungtis RO Conexiune la pământ SI Ozemljitvena povezava SK Uzemnenie</p>	 <p>EN Check sheet DE Blatt prüfen ES hoja de control FR Feuille de contrôle IT Controlla foglio PT Planilha de verificação NL Checklist DA Tjekark NO Skjekkliste SV Kontrollblad FI Tarkista arkki CS Zkontrolujte list HU Ellenőrző lap PL Sprawdz arkusz kontrolny EL Έλεγχος φύλλου RU Контрольный лист TR Kontrol sayfası BG Проверен лист EE Kontrolli leht LV Pārbaudes lapa LT Tikrinti lapą RO Foaie de verificare SI Kontrolni list SK Skontrolujte hárok</p>	
 =A <p>EN Mechanic DE Mechaniker ES Mecánico FR Mécanicien IT Meccanico PT Mecânico NL Monteur DA Mekaniker NO Mekaniker SV Mekaniker FI Mekaaninen CS Mechanik HU Szerelő PL Mechanik EL Μηχανικός RU Механик TR Tamirci BG механик EE Mehaanik LV Mehāniķis LT Mechanikas RO Mecanic SI Mehanik SK Mechanik</p>	 =B <p>EN Supervisor DE Supervisor ES Supervisor FR Superviseur IT Supervisore PT Supervisor NL Leidinggevende DA Tilsynsførende NO Veileder SV Handledare FI Valvoja CS Dozorce HU Felügyelő PL Kontroler EL Επόπτης RU Руководитель TR Süpervizör BG Ръководител EE Juhendaja LV Uzraugs LT Prižiūrėtojas RO Supraveghetor SI Nadzornik SK Dozorca</p>	 =OK <p>EN Visual check OK DE Kreuzen Sie OK an ES Verificar comprobador bien FR Vérification visuelle IT Spunta OK PT Verifique OK NL Vink OK aan DA Tjek OK NO Sjekk OK SV Zaškrtněte OK FI Tarkista OK CS Zaškrtněte OK HU Ellenőrizze az OK gombot PL Sprawdź OK EL Ελέγξτε το OK RU Проверить OK TR Tamam'i işaretleyin BG Проверете OK EE Kontrollige OK LV Pārbaudiet OK LT Patikrinkite Gerai RO Verificați OK SI Preverite OK SK Zaškrtnite OK</p>	 <p>EN Exterior damage check DE Äußere Schadensprüfung ES Comprobación de daños exteriores FR Vérification des dommages extérieurs IT Controllo danni esterni PT Verificação de danos externos NL Exterieur schade check DA Kontrol af udvendige skader NO Utvendig skadesjekk SV Kontroll av yttre skador FI Ulkoisten vaurioiden tarkastus CS Kontrola vnějšího poškození HU Külső sérülések ellenőrzése PL Kontrola uszkodzeń zewnętrznych EL Έλεγχος εξωτερικών ζημιών RU Проверка внешних повреждений TR Diş hasar kontrolü BG Проверка на външни повреди EE Välistkahjustuste kontroll LV Ārējo bojājumu pārbaude LT Išorinių pažeidimų patikrinimas RO Verificarea daunelor exterioare SI Zunanji pregled poškodb SK Kontrola vonkajšieho poškodenia</p>	 <p>EN Interior damage check DE Innere Schadensprüfung ES Comprobación de daños interiores FR Vérification des dommages intérieurs IT Controllo danni interni PT Verificação de danos internos NL Controle op schade aan interieur DA Indvendig skadekontrol NO Innvendig skadesjekk SV Invändig skadekontroll FI Sisävaurioiden tarkastus CS Kontrola poškození interiéru HU Belső sérülések ellenőrzése PL Kontrola uszkodzeń wewnętrznych EL Έλεγχος ζημιών στο εσωτερικό RU Проверка повреждений салона TR İç hasar kontrolü BG Проверка на вътрешни повреди EE Sisekahjustuste kontroll LV Lekšējo bojājumu pārbaude LT Vidaus pažeidimų patikrinimas RO Verificarea daunelor interioare SI Pregled notranjih poškodb SK Kontrola poškodenia interiéru</p>



















TOOLS

RATCHET	SMALL RATCHET	TORQUE WRENCH	HEXAGONAL SOCKET	HEXAGONAL DEEP SOCKET
				
PHILIPS SCREW DRIVER	SHORT SCREW DRIVER	FLAT SCREW DRIVER	HEXAGONAL SCREW DRIVER	TORX SCREW DRIVER
				
BREAKER BAR	EXTENSION BAR	TORQUE STICK	SPANNER	TORX SOCKET
				
DRILL	90° DRILL	COBALT DRILL BIT	COBALT DRILL BIT FOR PLASTIC	COBALT DRILL BIT FOR METAL
				
BULLET CRIMPING TOOL	WIRE STRIPPING TOOL	EYELET CRIMPING TOOL	ADJUSTABLE WRENCH	LONG NOSE PLIERS
				
POP RIVET TOOL	RIVNUT TOOL	TEMPERATURE SENSOR	HOT AIR TOOL	SOCKET/IMPACT TOOL
				






























TOOLS

<p>OSCILLATING SAW/ VIBRATING SAW</p> 	<p>BRADLE PICK</p> 	<p>SCRIBE TOOL</p> 	<p>METAL FILE</p> 	<p>METAL HACK SAW</p> 
<p>SAFETY CUTTER</p> 	<p>TIE WRAP CUTTER</p> 	<p>WIRE CUTTER</p> 	<p>CERAMIC CUTTER</p> 	<p>SCISSORS</p> 
<p>CONICAL DRILL</p> 	<p>HAMMER & PUNCH</p> 	<p>RUBBER Mallet</p> 	<p>HEX KEY</p> 	<p>HEX KEY EXTENSION</p> 
<p>TOP NOTCH SAW</p>  <p>PZ415-0JGS2-00</p>	<p>HOT GLUE APPLICATOR</p> 	<p>SEALANT APPLICATOR</p> 	<p>VACUUM CLEANER</p> 	<p>TAPE MEASURE</p> 
<p>DE-BURRING TOOL</p> 	<p>DE-BURRING TOOL</p> 	<p>CLIP REMOVAL TOOL</p> 	<p>PLASTIC TRIM REMOVAL TOOL</p> 	<p>PLASTIC TRIM REMOVAL TOOL</p> 
<p>PLIERS</p> 	<p>PRESSURE ROLLER</p> 	<p>MAGNET</p> 	<p>WIRE BRUSH</p> 	<p>WIRE FEEDER TOOL</p> 

TOOLS

TOYOTA GTS DIAGNOSTIC TOOL	TORCH	12V SOCKET TESTER	ELECTRICAL TESTER	STOP WATCH
				
STEP LADDER	4 POST CAR LIFT	2 POST CAR LIFT	TROLLEY JACK	ADJUSTABLE STAND
				
SPRAY DISPENSER	ASSIST GRIP REMOVAL TOOL	PILLAR GARNISH CLIP TOOL	PIN REMOVAL TOOL	
	 <div data-bbox="384 974 619 1014" style="background-color: #cccccc; padding: 2px;">09813-00010</div>	 <div data-bbox="683 974 917 1014" style="background-color: #cccccc; padding: 2px;">09813-00020</div>	 <div data-bbox="963 929 1222 1010" style="border: 1px solid black; padding: 2px;">  AIM 006 006-* </div>	
MIXING DISH	RULER			
				

CONSUMABLES

CLEANER / DEGREASER SPRAY    AIM 003 516-*		CAVITY WAX SPRAY  TEROSON WACHS USB SPRAY Ref: 794867  NOVATIO: SKIN COAT		THREAD LOCK 		LUBRICANT SPRAY 							
ADHESION PROMOTER  PZ415-00000-00		UNDER COATING SPRAY  SU001-B1673		VINYL APPLICATION FLUID  PW18A-0H000		SQUEEGEE  PZ438-00030-90		SOTT PINK SQUEEGEE  PW174-0H000					
MASKING TAPE 		ELECTRICAL TAPE 		BUTYL 3M 08611 Ø8 x 4.5m   Novatio Butaseal circular N° 551160390		MICROFIBRE CLOTH 		VEHICLE PROTECTION 					
SPONGE/WATER/BUCKET 		NON PERMANENT MARKER 		CHALK 		COTTON BUDS 		WORKSHOP PAPER TOWEL 					
		1K ANTI RUST PRODUCTS				2K ANTI RUST PRODUCTS							
		1st  NOVA POWER PAINT		2nd  NOVATIO SKIN COAT		A 		B 		A: DUPONT® 2K ETCHING PRIMER B: DUPONT® 2K ETCHING ADHESION  A: STANDOX® ETCHING ADHESION PRIMER 020 16167 B: STANDOX® ETCHING ADHESION ACTIVATOR 020 16168			

PERSONAL PROTECTION EQUIPMENT

PROTECTIVE GLOVES	FINIXA NITRIL GLOVES	KEVLAR GLOVES	FOREARM PROTECTION	SAFETY GLASSES
				
EAR DEFENDERS	SPRAY MASK	SAFETY CAP		
				