

All Models









Tools / Consumables / Personal Protection Equipment &
Symbols Description

Master

Latest Version
SCAN HERE



SYMBOLS EXPLANATION

| | | | | | |
|---|--|---|---|--|--|
|  <p> EN Correct DE Richtig ES Correcto FR Correct IT Guisto PT Correcto NL Correct DA Rigtigt NO Riktig SV Rätt FI Oikein CS Správně HU Helyes PL Prawidłowo EL Σωστό RU Правильно TR Doğru BG вярно ET Õige LV Pareizi LT Teisingai RO Corect SL Pravilno SK Správne </p> |  <p> EN Incorrect DE Falsch ES Incorrecto FR Incorrect IT Errato PT Incorreto NL Niet correct DA Ukorrekt NO Stemmer ikke SV Felaktig FI Väärä CS Nesprávný HU Helytelen PL Niepoprawnie EL Λάθος RU Неправильно TR Yanlış BG Неправилно ET Vale LV Nepareizi LT Teisingai RO Incorect SL Napačno SK Nesprávne </p> |  <p> EN Position arrow DE Positionspfeil ES Flecha de posición FR Flèche de positionnement IT Freccia di posizione PT Seta de posição NL Positie pijl DA Positionspil NO Posisjonspil SV Positionspil FI Sijoitusnuoli CS Šipka polohy HU Strípka pozíciója PL Strzałka pozycji EL Τοποθέτηση βέλους RU Стрелка положения TR Strelka oku BG Стрелка за позиция ET Positsiooninool LV Pozīcijas bultiņa LT Padėties rodyklė RO Săgeată de poziție SL Pozicijska puščica SK Polohovacia šípka </p> |  <p> EN Movement arrow DE Bewegungspfeil ES Flecha de movimiento FR Flèche de mouvement IT Freccia di movimento PT Seta de movimento NL Beweging pijl DA Bevægelse pil NO Bevegelsespil SV Rörelsepil FI Liike nuoli CS Šipka pohybu HU Mozgás nyíl PL Strzałka kierunku EL Βέλος κίνησης RU Стрелка движения TR Hareket oku BG Стрелка за движение ET Liikumise nool LV kustības bultiņa LT Judėjimo rodyklė RO Săgeată de mișcare SL Puščica za gibanje SK Šipka pohybu </p> |  <p> EN Partial removal DE Teilentfernung ES Eliminación parcial FR Désassemblage partiel IT Rimozione parziale PT Remoção parcial NL Gedeeltelijke verwijdering DA Delvis fjernelse NO Delvis fjerning SV Partiell borttagning FI Osittainen poisto CS Částečné odstranění HU Részleges eltávolítás PL Częściowe usunięcie EL Μερική αφαίρεση RU Частичное удаление TR Kısmi kaldırma BG Частично премахване ET Osaline eemaldamine LV Daļēja noņemšana LT Dalinis pašalinimas RO Îndepărtarea parțială SL Delna odstranitev SK Čiastočné odstránenie </p> |  <p> EN Turn part DE Teil drehen ES Girar la pieza FR Retourner la pièce IT Gira parte PT Parte de volta NL Draai deel DA Vend del NO Snu en del SV Vänd del FI Käännä osa CS Otočte část HU Fordítsa alkatrészt PL Rotacja EL Γυρίστε μέρος RU Поверните часть TR Parçayı çevir BG Обърнете част ET Pöörake osa LV Pagrieziet daļu LT Pasukite dalį RO Rotiți partea SL Obrnite del SK Otočte časť </p> |
|  <p> EN Disconnect DE Trennen ES Desconectar FR Déconnecter IT Disconnetti PT Desconectar NL Verbinding verbreken DA Koble fra NO Koble fra SV Koppla ifrån FI Katkaista CS Odpojit HU Leválasztás PL Rozłączyć się EL Αποσυνδέω RU Отключить TR Bağlantıyı kes BG Прекъснете връзката ET Katkesta ühendus LV Atvienot LT Atsijungti RO Deconectat SL Prekinii povezavo SK Odpojit </p> |  <p> EN Connect DE Anschließen ES Conectar FR Connecter IT Collegare PT Conectar NL Aansluiten DA Opret forbindelse NO Koble SV Ansluta FI Kytkeä CS Připojit HU Csatlakozás PL Połączyć EL Συνδέω-συνδεομαι RU Соединять TR Bağlamak BG Свържете се ET Ühendage LV Savienot LT Prisijungti RO Conectați SL Povežite se SK Pripojte sa </p> |  <p> EN Disconnect fluid DE Flüssigkeit trennen ES Desconecte el fluido FR Déconnecter tuyaux IT Scollegare il fluido PT Desconecte o fluido NL Vloeistof loskoppelen DA Frakobl væsken NO Koble fra væsken SV Koppla bort vätskan FI Irrota neste CS Odpojte kapalinu HU Kösse le a folyadékot PL Odłączyć płyn EL Αποσυνδέστε το υγρό RU Отсоедините жидкость TR Sivi bağlantısını kesin BG Изключете течността ET Ühendage vedelik lahti LV Atvienojiet šķidrumu LT Atjunkite skystį RO Deconectați lichidul SL Odklopite tekočino SK Odpojte kvapalinu </p> |  <p> EN Connect fluid DE Flüssigkeit anschließen ES Conectar fluido FR Connecter tuyaux IT Collegare il fluido PT Conecte o fluido NL Vloeistof aansluiten DA Tilslut væske NO Koble til væske SV Anslut vätska FI Liitä neste CS Připojte kapalinu HU Csatlakoztassa a folyadékot PL Podłączyć płyn EL Συνδέστε το υγρό RU Подключить жидкость TR Sıvıyı bağlayın BG Свържете течност ET Ühendage vedelik LV Pievienojiet šķidrumu LT Prijunkite skystį RO Conectați fluidul SL Priključite tekočino SK Pripojte kvapalinu </p> |  <p> EN Airbag DE Airbag ES Bolsa de airbag FR Airbag IT Airbag PT Airbag NL Airbag DA Airbag NO Airbag SV Krockkudde FI Airbag CS Airbag HU Légzsák PL Poduszka powietrzna EL Αερόσακός RU Воздушная подушка TR Hava yastığı BG Въздушна възглавница ET Turvapadi LV Gaisa spilvens LT Oro pagalvė RO Airbag SL Zračna blazina SK Airbag </p> | |
|  <p> EN Information DE Information ES Información FR Information IT Informazione PT Em formação NL Informatie DA Information NO Informasjon SV Information FI Tiedot CS Informace HU Információ PL Informacja EL Πληροφορίες RU Информация TR Bilgi BG Информация ET Teave LV Informācija LT Informacija RO Informație SL Informacije SK Informácie </p> |  <p> EN See reference DE Siehe Referenz ES Ver referencia FR Voir référence IT Vedi riferimento PT Ver referência NL Zie referentie DA Se reference NO Se referanse SV Se referens FI Katso viite CS Viz odkaz HU Lásd a hivatkozást PL Zobacz referencję EL Βλέπε παραπομπή RU См. ссылку TR Referansa bakın BG Вижте справка ET Vaata viidet LV Skatīt atsauci LT Žr. nuorodą RO Vezi referința SL Glej referenco SK Pozri referenciu </p> |  <p> EN Look/See DE Schau ES Ver FR Regarder IT Guarda PT Olhar/Ver NL Kijk zie DA Se NO Se SV Titta/se FI Katso CS Podívejte se/vidíte HU Nézd/Lásd PL Spójrz/Zobacz EL Κοίτα δεξ RU Смотриеть видеть TR Bak/Gör BG Вижте ET Vaata LV Skaties/redzi LT Pažiūrėk RO Uite/Vezi SL Pogledj/glej SK Pozri </p> |  <p> EN Warning DE Warnung ES Advertencia FR Avertissement IT Avvertimento PT Aviso NL Waarschuwing DA Advarsel NO Advarsel SV Varning FI Varoitus CS Varování HU Figyelem PL Ostrzeżenie EL Προειδοποίηση RU Предупреждение TR Uyarı BG Внимание ET Hoiatu LV Brīdinājums LT Įspėjimas RO Avertizare SL Opozorilo SK Pozor </p> |  <p> EN Safety critical DE Sicherheitskritisch ES Seguridad crítica FR Sécurité critique IT Sicurezza critica PT Segurança crítica NL Cruciaal voor de veiligheid DA Sikkerhed kritisk NO Sikkerhet kritisk SV Säkerhet kritisk FI Turvallisuukskriittinen CS Bezpečnost kritická HU Biztonság kritikus PL Operacja krytyczna bezpieczeństwa EL Η ασφάλεια είναι κρίσιμη RU Критическая безопасность TR Emniyet açısından kritik BG Критично за безопасността ET Ohutuskiitiline LV Drošībai kritiski svarīgi LT Saugumas kritinis RO Siguranța critică SL Varnost kritična SK Bezpečnosť' kritická </p> | |

SYMBOLS EXPLANATION




- EN Don't touch
- DE Nicht berühren
- ES No tocar
- FR Ne touchez pas
- IT Non toccare
- PT Não toque
- NL niet aanraken
- DA rør ikke
- NO ikke rør
- SV Rör inte
- FI Älä koske
- CS Nedotýkejte se
- HU Ne érintse meg
- PL Nie dotykaj
- EL Μην αγγίζετε
- RU Не трогай
- TR dokunma
- BG Не докосвайте
- ET Ärge puudutage
- LV Neaizietciēt
- LT Nelieskite
- RO nu atinge
- SL Ne dotikajte se
- SK Nedotýkajte sa



- EN Hand tighten
- DE Handfest anziehen
- ES Apretar con la mano
- FR Serrer à la main
- IT Stringere a mano
- PT Apertar com a mão
- NL Handvast aandraaien
- DA Stram med hånden
- NO Stram for hånd
- SV Dra åt för hand
- FI Kiristää käsin
- CS Utáhněte rukou
- HU Kézzel húzza meg
- PL Dokręcić ręcznie
- EL Σφίξτε το χέρι
- RU Затянуть вручную
- TR Elle sıkın
- BG Затегнете с ръка
- ET Pingutage käsitsi
- LV Pievelciēt roku
- LT Ranka priveržkite
- RO Strângeți cu mâna
- SL Ročno zategnite
- SK Dotiahnite rukou




- EN Centre line
- DE Mittellinie
- ES Línea central
- FR Ligne médiane
- IT Linea centrale
- PT Linha central
- NL Middenlijn
- DA Midterlinje
- NO Midtlinje
- SV Mittlinje
- FI Keskilinja
- CS Středová čára
- HU Középvonal
- PL Linia środkowa
- EL Κεντρική γραμμή
- RU Центральная линия
- TR Merkez hattı
- BG Централна линия
- ET Keskjoon
- LV Centra līnija
- LT Centrinė linija
- RO Linia centrală
- SL Sredinska črta
- SK Stredová čiara



- EN 2 Person operation
- DE 2-Personen-Betrieb
- ES Opération à 2 personnes
- FR Fonctionnement à 2 personnes
- IT Operazione a 2 persone
- PT Operação de 2 pessoas
- NL Bediening voor 2 personen
- DA 2 Persons betjening
- NO 2 Person drift
- SV 2 personers drift
- FI 2 henkilön toiminta
- CS Obsluha 2 osobami
- HU 2 személyes működtetés
- PL Obsługa 2 osób
- EL Λειτουργία 2 ατόμων
- RU 2 человека операции
- TR 2 kişilik operasyon
- BG Операция на 2 човека
- ET 2 inimese operatsioon
- LV 2 Personas darbība
- LT 2 asmenų operacija
- RO Operare cu 2 persoane
- SL Delovanje 2 oseb
- SK Obsluha 2 osobami



- EN Throw away / Recycle
- DE Wegschmeißen / Recyclen
- ES Tirar a la basura / Reciclar
- FR Jeter / Recycler
- IT Buttar via / Ricicla
- PT Jogar fora / Reciclagem
- NL Weggoeien / Recyclen
- DA Smid væk / Genbrug
- NO Kast / Resirkulering
- SV Kasta iväg / Återvinna
- FI Heittää pois / Kierrättää
- CS Zahodit / Recyklovat
- HU Dobd el / Újrahasznosít
- PL Wyrzucić / Recykling
- EL Πετάω / Ανακυκλώνω
- RU Выбросить / Рециркулировать
- TR Atmak / Geri dönmüşüm
- BG Изхвърлям / Рециклиране
- ET Viska minema / Taaskasutada
- LV Izmetiet / Pārstrādāt
- LT Išmesti / Perdirbti
- RO Aruncă / Reciclează
- SL Vrzi stran / Recikliraj
- SK Zahodit' / Recyklovat'



- EN Vehicle direction
- DE Fahrzeugrichtung
- ES Dirección del vehículo
- FR Sens du véhicule
- IT Direzione del veicolo
- PT Direção do veículo
- NL Voertuig richting
- DA Køretøjets retning
- NO Kjøretøy retning
- SV Fordonets riktning
- FI Ajoneuvon suunta
- CS Směr vozidla
- HU A jármű iránya
- PL Kierunek pojazdu
- EL Κατεύθυνση οχήματος
- RU Направление автомобиля
- TR Araç yönü
- BG Посоката на превозното средство
- ET Sõiduki suund
- LV Transportlīdzekļa virziens
- LT Transporto priemonės kryptis
- RO Direcția vehiculului
- SL Smer vozila
- SK Smer vozidla



- EN LHD/RHD drive
- DE LHD/RHD-Antrieb
- ES Unidad LHD/RHD conducción
- FR Conduite à gauche/conduite à droite
- IT Guida a sinistra/destra
- PT Unidade LHD/RHD
- NL LHD/RHD-aandrijving
- DA LHD/RHD drev
- NO LHD/RHD-stasjon
- SV LHD/RHD-enhet
- FI LHD/RHD-aseama
- CS Pohon LHD/RHD
- HU LHD/RHD meghajtó
- PL Kierownica LHD RHD
- EL Μονάδα δίσκου LHD/RHD
- RU леворульный/правосторонний привод
- TR LHD/RHD sürücü
- BG LHD/RHD задвижване
- ET LHD/RHD draiv
- LV LHD/RHD disks
- LT LHD/RHD diskas
- RO Unitate LHD/RHD
- SL LHD/RHD pogon
- SK Pohon LHD/RHD



- EN Earth connection
- DE Masseanschluss
- ES Conexión a tierra
- FR Connexion à la terre
- IT Collegamento a terra
- PT Conexão à terra
- NL Aardverbinding
- DA Jordforbindelse
- NO Jordforbindelse
- SV Jordanslutning
- FI Maaliitäntä
- CS Zemní spojení
- HU Föld csatlakozás
- PL Masa
- EL Σύνδεση γείωσης
- RU Заземление
- TR Dünya bağlantısı
- BG Земна връзка
- ET Maandusühendus
- LV Zemes savienojums
- LT Įžeminimo jungtis
- RO Conexiune la pământ
- SL Ozemljitvena povezava
- SK Uzemnenie



- EN Check sheet
- DE Blatt prüfen
- ES hoja de control
- FR Feuille de contrôle
- IT Controlla foglio
- PT Planilha de verificação
- NL Checklist
- DA Tjekark
- NO Skjekkliste
- SV Kontrollblad
- FI Tarkista arkki
- CS Zkontrolujte list
- HU Ellenőrző lap
- PL Sprawdz arkusz kontrolny
- EL Έλεγχος φύλλου
- RU Контрольный лист
- TR Kontrol sayfası
- BG Проверен лист
- ET Kontrolli leht
- LV Pārbaudes lapa
- LT Tikrinti lapą
- RO Foaie de verificare
- SL Kontrolni list
- SK Skontrolujte hárok



- EN Mechanic
- DE Mechaniker
- ES Mecánico
- FR Mécanicien
- IT Meccanico
- PT Mecânico
- NL Monteur
- DA Mekaniker
- NO Mekaniker
- SV Mekaniker
- FI Mekaaninen
- CS Mechanik
- HU Szerelő
- PL Mechanik
- EL Μηχανικός
- RU Механик
- TR Tamirci
- BG механик
- ET Mehaanik
- LV Mehāniķis
- LT Mechanikas
- RO Mecanic
- SL Mehanik
- SK Mechanik



- EN Supervisor
- DE Supervisor
- ES Supervisor
- FR Superviseur
- IT Supervisore
- PT Supervisor
- NL Leidinggevende
- DA Tilsynsførende
- NO Veileder
- SV Handledare
- FI Valvoja
- CS Dozorce
- HU Felügyelő
- PL Kontroler
- EL Επόπτης
- RU Руководитель
- TR Süpervizör
- BG Ръководител
- ET Juhendaja
- LV Uzraugs
- LT Prižiūrėtojas
- RO Supraveghetor
- SL Nadzornik
- SK Dozorca



- EN Visual check OK
- DE Kreuzen Sie OK an
- ES Verificar comprobador bien
- FR Vérification visuelle
- IT Spunta OK
- PT Verifique OK
- NL Vink OK aan
- DA Tjek OK
- NO Sjekk OK
- SV Zaškrtněte OK
- FI Tarkista OK
- CS Zaškrtněte OK
- HU Ellenőrizze az OK gombot
- PL Sprawdź OK
- EL Ελέγξτε το OK
- RU Проверить OK
- TR Tamam' i işaretleyin
- BG Проверете OK
- ET Kontrollige OK
- LV Pārbaudiet OK
- LT Patikrinkite Gerai
- RO Verificați OK
- SL Preverite OK
- SK Zaškrtnite OK

































- EN Exterior damage check
- DE Äußere Schadensprüfung
- ES Comprobación de daños exteriores
- FR Vérification des dommages extérieurs
- IT Controllo danni esterni
- PT Verificação de danos externos
- NL Exterieur schade check
- DA Kontrol af udvendige skader
- NO Utvendig skadesjekk
- SV Kontroll av yttre skador
- FI Ulkoisten vaurioiden tarkastus
- CS Kontrola vnějšího poškození
- HU Külső sérülések ellenőrzése
- PL Kontrola uszkodzeń zewnętrznych
- EL Έλεγχος εξωτερικών ζημιών
- RU Проверка внешних повреждений
- TR Diş hasar kontrolü
- BG Проверка на външни повреди
- ET Väliskahjustuste kontroll
- LV Ārējo bojājumu pārbaude
- LT Išorinių pažeidimų patikrinimas
- RO Verificarea daunelor exterioare
- SL Zunanji pregled poškodb
- SK Kontrola vonkajšieho poškodenia



- EN Interior damage check
- DE Innere Schadensprüfung
- ES Comprobación de daños interiores
- FR Vérification des dommages intérieurs
- IT Controllo danni interni
- PT Verificação de danos internos
- NL Controle op schade aan interieur
- DA Indvendig skadekontrol
- NO Innvendig skadesjekk
- SV Invändig skadekontroll
- FI Sisävaurioiden tarkastus
- CS Kontrola poškození interiéru
- HU Belső sérülések ellenőrzése
- PL Kontrola uszkodzeń wewnętrznych
- EL Έλεγχος ζημιών στο εσωτερικό
- RU Проверка повреждений салона
- TR İç hasar kontrolü
- BG Проверка на вътрешни повреди
- ET Sisekahjustuste kontroll
- LV Iekšējo bojājumu pārbaude
- LT Vidaus pažeidimų patikrinimas
- RO Verificarea daunelor interioare
- SL Pregled notranjih poškodb
- SK Kontrola poškodenia interiéru
















TOOLS

| RATCHET | SMALL RATCHET | TORQUE WRENCH | HEXAGONAL SOCKET | HEXAGONAL DEEP SOCKET |
|---|---|---|---|---|
|  |  |  |  |  |
| PHILIPS SCREW DRIVER | SHORT SCREW DRIVER | FLAT SCREW DRIVER | HEXAGONAL SCREW DRIVER | TORX SCREW DRIVER |
|  |  |  |  |  |
| BREAKER BAR | EXTENSION BAR | TORQUE STICK | SPANNER | TORX SOCKET |
|  |  |  |  |  |
| DRILL | 90° DRILL | COBALT DRILL BIT | COBALT DRILL BIT FOR PLASTIC | COBALT DRILL BIT FOR METAL |
|  |  |  |  |  |
| BULLET CRIMPING TOOL | WIRE STRIPPING TOOL | EYELET CRIMPING TOOL | ADJUSTABLE WRENCH | LONG NOSE PLIERS |
|  |  |  |  |  |
| POP RIVET TOOL | RIVNUT TOOL | TEMPERATURE SENSOR | HOT AIR TOOL | SOCKET/IMPACT TOOL |
|  |  |  |  |  |



TOOLS

| | | | | |
|---|---|--|--|---|
| <p>OSCILLATING SAW/ VIBRATING SAW</p>  | <p>BRADLE PICK</p>  | <p>SCRIBE TOOL</p>  | <p>METAL FILE</p>  | <p>METAL HACK SAW</p>  |
| <p>SAFETY CUTTER</p>  | <p>TIE WRAP CUTTER</p>  | <p>WIRE CUTTER</p>  | <p>CERAMIC CUTTER</p>  | <p>SCISSORS</p>  |
| <p>CONICAL DRILL</p>  | <p>HAMMER & PUNCH</p>  | <p>RUBBER Mallet</p>  | <p>HEX KEY</p>  | <p>HEX KEY EXTENSION</p>  |
| <p>TOP NOTCH SAW</p>  <p>PZ415-0JGS2-00</p> | <p>HOT GLUE APPLICATOR</p>  | <p>SEALANT APPLICATOR</p>  | <p>VACUUM CLEANER</p>  | <p>TAPE MEASURE</p>  |
| <p>DE-BURRING TOOL</p>  | <p>DE-BURRING TOOL</p>  | <p>CLIP REMOVAL TOOL</p>  | <p>PLASTIC TRIM REMOVAL TOOL</p>  | <p>PLASTIC TRIM REMOVAL TOOL</p>  |
| <p>PLIERS</p>  | <p>PRESSURE ROLLER</p>  | <p>MAGNET</p>  | <p>WIRE BRUSH</p>  | <p>WIRE FEEDER TOOL</p>  |

TOOLS

| TOYOTA GTS DIAGNOSTIC TOOL | TORCH | 12V SOCKET TESTER | ELECTRICAL TESTER | STOP WATCH |
|--|---|---|---|--|
|  |  |  |  |  |
| STEP LADDER | 4 POST CAR LIFT | 2 POST CAR LIFT | TROLLEY JACK | ADJUSTABLE STAND |
|  |  |  |  |  |
| SPRAY DISPENSER | MIXING DISH | | PIN REMOVAL TOOL | |
|  |  | |   AIM 006 006-* |  |

CONSUMABLES

| CLEANER / DEGREASER SPRAY | | CAVITY WAX SPRAY | THREAD LOCK | LUBRICANT SPRAY |
|---|--|---|--|---|
|    AIM 003 516-* | |  Teroson wachs USB spray Ref: 794867 or Novatio Skin Coat |  |  |
| ADHESION PROMOTER | UNDER COATING SPRAY | VINYL APPLICATION FLUID | SQUEEGEE | WORKSHOP PAPER TOWEL |
|  PZ415-00000-00 |  SU001-B1673 |  PW18A-0H000 |  PZ438-00030-90 |  |
| MASKING TAPE | ELECTRICAL TAPE | BUTYL | MICROFIBRE CLOTH | PROTECTIVE BLANKET |
|  |  | 3M 08611 Ø8 x 4.5m  or Novatio Butaseal circular N° 551160390 |  |  |
| SPONGE/WATER/BUCKET | NON PERMANENT MARKER | CHALK | COTTON BUDS | |
|  |  |  |  | |
| | 1K ANTI RUST PRODUCTS | | 2K ANTI RUST PRODUCTS | |
| | 1st  NOVA POWER PAINT | 2nd  NOVATIO SKINCOAT | A  ETCHING PRIMER | B  ACTIVATOR |
| | | | A: Standox® Etching Adhesion Primer 020 16167 B: Standox® Etching Adhesion Activator 020 16168 or A: Sikkens® primer surfacer EP II B: Sikkens® primer surfacer EP II Hardener |  |

PERSONAL PROTECTION EQUIPMENT

| PROTECTIVE GLOVES | FINIXA NITRIL GLOVES | KEVLAR GLOVES | FOREARM PROTECTION | SAFETY GLASSES |
|--|---|---|--|---|
|  |  |  |  |  |
| EAR DEFENDERS | SPRAY MASK | SAFETY CAP | | |
|  |  |  | | |