







**MAINTENANCE SCHEDULE - EUROPE 15,000 km/9,000 miles**

**MAINTENANCE OPERATIONS**

I: Inspect and correct or replace as necessary. T: Tighten to specified torque.  
R: Replace or change or lubricate. C: Clean

**CHASSIS AND BODY 2/2**

SERVICE INTERVALS:				ODOMETER READING												Starting Year/Month of Production	Model Code							
Odometer reading or months, whichever comes first																								
				Months																				
				× 1,000 km	1	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90							
MAINTENANCE ITEMS				× 1,000 miles	1	5	10	15	20	25	30	35	40	45	50	55	60	2009/08	2009/08	2013/08 (MC)	2015/06	2017/08 (MC)		
Front Differential oil	Differential integrated with transmission	M/T model	API Gear oil GL-4 or GL-5	Normal									I					Every 48 months						
			Severe											R					Every 48 months					
		A/T model	LV Gear oil API GL-4	Normal											I					Every 48 months				
			Severe												R					Every 48 months				
		Toyota Genuine ATF WS	Normal												I				I	Every 36 months				
			Normal												I				I	Every 48 months				
	Severe													I				R	I: Every 36 months R: Every 72 months					
	Normal													I				R	Every 48 months					
	Toyota Genuine CVTF TC	Normal												I				R	I: Every 36 months R: Every 72 months					
		Severe												I				R	Every 48 months					
Toyota Genuine CVTF FE	Normal												I				R	I: Every 36 months R: Every 72 months						
	Severe												I				R	Every 48 months						
Differential separated from transmission (API Gear oil GL-5)																		R	Every 48 months					
Rear differential oil	API Gear oil GL-5			Normal														R	Every 48 months					
	RAV4 HV (4WD), NX300h (4WD) and RX450h/450hL (4WD) only			Normal														I	Every 36 months					
Wheel bearing grease (tapered roller type wheel bearing only) and ball joint grease	NLGI No. 2			Normal														R	Every 24 months					
	Severe					R				R								R	Every 12 months					
Front and rear suspension	Normal																	I	Every 24 months					
	Severe					I				I								I	Every 12 months					
Active height control suspension fluid - Suspension fluid AHC or equivalent																		R						
Active height control gas chamber																			I	I: initial 48 months; then every 12 months				
Bolts and nuts on chassis and body *2				Severe only			T		T		T		T		T		T	T	Every 12 months					
Tyres and inflation pressure, lights, wiper blades and washer fluid	Normal																	I	Every 24 months					
	Severe					I				I								I	Every 12 months					
A/C filter- Particle filter	Pollen removal type	Stamped "C", "E", "K", or "N"	Normal															R	"Clean" replaced by "Inspect"					
			Dusty road*4																R	Refer to TME letter of October 2007				
		1*																	R					
		Normal																	R	on "Potential Health Risk From Cleaning of Cabin Air Filter Elements"				
	Stamped "P" or "L"	Dusty road*4																	R					
		1*																	R					
Standard type & high efficiency type	Normal																	R						
	Dusty road*4																	R						
A/C filter - Combination filter	High efficiency type	Normal																	R					
		Dusty road*4																	R					
		Normal*3																	R	Every 12 months				
		Dusty road*4																	R	Every 12 months				
Air conditioner filter Aygo only																		R						
Corrosion Inspection																		I	Every 24 months					

1\*: with Solar power ventilation system  
2\*: For seat mounting bolts, front and rear suspension member retaining bolts.  
3\*: For New models, model changed or minor change vehicles, produced from January 2015  
4\*: Roads in area where the pavement rate is low, or a cloud of dust often arises and the air is dry