After PDS (Pre-Delivery Service), vehicles undergo various phases such as being displayed in the showroom, placed in inventory, or having dealer option installed before delivering to customers. During the phases, vehicles could possibly sustain damage. Therefore, make sure to carry out the inspections and preparation for delivery to customer described herein immediately prior to delivery to customer.
Also problems which are likely to cause customer complaints must be thoroughly repaired.



Wash the vehicle.



Check for the installation of fuse(s).



Check the washer fluid level, and replenish if necessary.



Engine startability for battery condition.

If any problem such as a poor battery, etc. is found, it should be charged.

NOTE:
If the vehicle is stored over one month, check the battery remaining capacity.



Audio system and clock for presetting.

If they are not set correctly, adjust them.



Check the vehicle interior for dirt and scratches.

Problems which are likely to cause customer complaint must be thoroughly repaired.



Check the vehicle exterior for scratches (superficial, subsurface scratches, chip) and rust.

HINT:
See the inspection procedure (on-ground inspection) under Vehicle Receiving Inspection.



Check all tires for deformation and defect.



Check the installation of distributor- and dealer-installed parts.

Check the installation of loaded parts (jack, tools and manuals).



Remove the following parts:

- Plastic door edge protectors



- Seat and door trim protection covers
- Floor carpet protection covers (paper)
- Step covers
- Other covers such as sun visor cover



Clean the vehicle interior.

HINT:
If using a vacuum cleaner, handle it carefully in order to avoid damaging the vehicle.



Explain to customers.

- Owner's manual
- Operation of features and accessories
- Required maintenance schedule
- Service department operation
- Introduction of customer to service manager